

A wireless switch output device

Milad Hajihassan

https://github.com/milador/M5-Access-Switch-Output

Contents

Usage Components	Usage requirements	
Usage Process		
	Usage Components	
How to Use?	Usage Process	2
	How to Use?	
Sleep Mode		

Usage requirements

Usage Components

1. Mono Audio Jack Cable x 2

Usage Process

How to Use?

- 1. Connect the Switch Output module through two 3.5mm Mono Audio jack cables to two adapted devices.
 - 1.1. Switch A
 - 1.2. Switch B
- 2. Connect to the Access Point (Example: Windows 10 PC)

On Windows 10:

- 2.1. Select Start > Settings > Network & Internet > Show available networks. Select M5SwitchOutput network and click on connect. The default network password is 123456.
- 3. M5StackC will display an IP address on its display screen.
- 4. Open your favourite web browser software.
- 5. Enter the IP address from step 3 to access switch output control web page.
- 6. You can now send switch actions by pressing each switch button.

Sleep Mode

The device goes to sleep mode if it's not used for more than one minute and automatically wakes up every 3 minutes.